


TouchRight Utilities

FEATURES

- Adds right mouse button functionality to your touch or pen environment
- On-Screen button provides instant access to Context Menus, Property sheets, etc
- Hot switch from Left Button to Right Button and back again
- Easy access to Cut, Copy, Paste, Properties, View, Send To, Delete, etc
- Features such as Restart Windows, Exit Windows, and Reboot System available
- Graphic display indicates current status of Left and Right Button
- For Windows 3.x, Windows 95/98/Me, Windows NT, Windows 2000



This useful utility gives the user Right-Click access for touchscreens and pens.

TouchRight Utilities

An easy interface to bring Right Click capability to ANY Touchscreen. Great for users, developers, integrators, or administrators to work with and configure touchscreen applications.

Why do I need this?

Most touchscreen drivers enable a "touch" or "press" to act as the left button click of a mouse. The act of pointing is very intuitive on a touchscreen, i.e. you point! To interface with windows, the act of "touching" the screen is converted into a left click (as though you used the mouse to point to the button/area) and then "clicked" to select/press button. Since the screen IS the interface, there is no intuitive way to implement a Right-Click (No, you cannot use your other hand!). However, using the Right-Click can be important when working with systems (especially in Windows 95/98/Me, Windows NT/2000), so by using "TouchRight", you can easily access the system by changing back and forth between Left Click and Right Click!

How do I right click?

On a standard touchscreen with a standard driver, you can't - in Windows 95/98/Me/NT/2000 this is especially frustrating. But with "TouchRight" a simple touch turns your touch into a Right Click instead of a Left Click. Touch again, and you're back to the standard Left Click.

What else do I get?

The TouchRight Utilities includes various useful functions:

- Always Topmost - this feature keeps the touchright window visible for easy access, but can be turned off when you want your screen real-estate back!
- Hide until Taskbar Active - this allows you to hide the window to retrieve full screen visibility, but by simply clicking on the Windows Taskbar, you can immediately see the TouchRight window again! (New in 1.20)
- Single Right-Click Only - this option automatically returns to the default Left-Click after a single Right-Click action - great for quick "clicking"
- The ability to Shutdown Windows, Exit (Logoff) Windows, and reboot your system are available.

Software Requirements

Windows 3.x, Windows 95/98/Me, Windows NT, Windows 2000/XP

Compatible

Works with ANY Pen or Touchscreen - Easy to use!